


General Information

LIGHTWEAVES® CORDLESS SHADE PRODUCT DETAIL



NOTE: All Cordless shades need to be used on windows where the consumer can comfortably raise and lower the shade with their hand and have easy access. Very high or hard-to-reach windows should use Continuous-loop, Smart Pull or Motorized Lift shades, rather than Cordless.